


### Snipped Inside/Outside Corners:

#### Step 1:

Snip the small return leg at top/back just under the bubble gasket. Do not snip through the bubble gasket.

#### Step 1:



#### Step 2:

Snip  $\frac{1}{8}$ " on the bottom of the Fire Gasket.


#### Step 2:



#### Step 3:

Lightly score the intumescent and foam tapes with utility knife to keep it from ripping when bent. Do not cut all the way through the tapes.


#### Step 3:



#### Step 4:

Bend Fire Gasket to meet the inside or outside corner and fasten into place with the foam tape and optionally with  $\frac{1}{2}$ " framing screws through the lower adhesive area of the bead.

#### Step 4:



### Snipped Horizontal to Vertical Joint:

#### Step 1:

Measure horizontal leg to length and snip off a flat  $45^\circ$  triangular section of the product.

#### Step 1:



#### Step 2:

Repeat with the vertical leg, and on install, ensure there are no gaps where the intumescent tape meets.

#### Step 2:



**Mitered Horizontal to  
Vertical Joint:**


**Step 1:**

Measure top leg to length. Lay product flat on miter saw and make appropriate 45° cut, ensuring product is oriented properly.

**Step 2:**

Repeat with vertical leg, and on install, ensure there are no gaps where the intumescent tape meets.

**Step 1:**



**Step 2:**

